IRONCREST

IRON CREST ARCHERY BACKSTOP SYSTEM

ASSEMBLY & INSTALLATION GUIDE

7.2 x 6 FT (2.2 x 1.8 M)

PARTS INCLUDED

1	2	3	4	5	6	7	8	HARDWARE	Fabric Panel	Elastic Ball Ties	Tools Included
Angled Top Tube	Angled Top Tube	Vertical Tube	Lower Vertical Tube	Base Tube (T-Base)	Bottom Bar	Bottom Bar	Diagonal Brace	Bolt 6 pcs Washer 6 pcs Nut 6 pcs			Open-End Wrench Allen Key
1 pc	1 pc	2 pcs	2 pcs	2 pcs	1 pc	1 pc	4 pcs		1 pc	21 pcs	1 pc each

1 BUILD EACH BOTTOM CORNER



Take one T-base (part 5) and two diagonal braces (part 8).

Screw both diagonal braces onto the T-base using the bolts and nuts provided, tightened with the wrench and Allen key.

Press the T-base assembly onto part 4 until the push pin clicks and locks.

Attach the top ends of both diagonal braces to the tube (part 4), securing with bolts.

2 ATTACH THE VERTICAL TUBES

(Repeat once per side)



Insert the bottom end of vertical tube (3) into the top of tube (4).

Push the button to lock in place.

Make sure it is fully engaged.

3 CONNECT THE TOP RAIL



Insert the top of the vertical tubes (3) into the angled top tubes (1) and (2).

Push the buttons to lock in place.

Make sure they are fully engaged.

4 CONNECT THE BOTTOM RAIL



Insert bottom bars (6) and (7) into the T-bases (5) at each corner.

Push the buttons to lock in place.

Make sure they are fully engaged.

5 FRAME ASSEMBLED



The frame is now fully assembled. Make sure all buttons are locked in place before attaching the fabric.

6 ATTACH THE FABRIC



1. Drape the fabric over the frame.
2. Start at one top corner.
3. Insert an elastic ball tie through the grommet.
4. Loop the tie around the frame tube and secure it.
5. Continue around the entire perimeter.
6. Make sure the fabric is evenly tensioned with no sagging.

7 FINAL CHECK

- ✓ All buttons are locked.
- ✓ Frame is stable and does not wobble.
- ✓ Fabric is properly attached and evenly tensioned.
- ✓ No parts are damaged.

! DO NOT USE THE BACKSTOP IF ANY COMPONENT IS DAMAGED, LOOSE, OR NOT FULLY SECURED.

8 OPTIONAL – ADD SAND BAGS



For additional stability, place one sandbag on each base.

INTENDED FOR ARCHERY USE ONLY. ALWAYS USE APPROPRIATE ARROWS AND SHOOT FROM A SAFE DISTANCE. KEEP CHILDREN AND PETS AWAY FROM THE SHOOTING AREA.